



Mark screw location, ensure that Buckeye ECO EDGE™ is level



Hang ECO EDGE by top two screws, and then insert bottom screw (Access Hole)

Connect water inlet hose to faucet

Connect ECO packaging to proper Quick Connect



Vacuum Breaker Assembly Instructions:



⚠ Important Information


1. Check water pressure (30 - 80 PSI)
 2. Tighten the vacuum breaker onto a fixed, hard plumbed water faucet, ensuring that the vacuum breaker is installed upright on a vertical plane.
 3. Connect the inlet hose onto the vacuum breaker.
 4. Place vacuum breaker cover over the vacuum breaker to prevent water from splashing out.
 5. Ensure hot water fixture is turned off when ECO proportioning system is not in use.
- Mount ECO EDGE directly over a sink or floor drain, approximately 4 feet above floor.
 - Water Supply Pressure:
 - 30 psi Minimum, 80 psi Maximum
 - Backflow Prevention:
 - Per local plumbing code
 - Check Level:
 - To ensure ECO system is level
 - Water Temperature:
 - 40°F (4°C) minimum, 120°F (50°C) Maximum



* In cases where an installation involves a water source coming from a faucet with an integrated vacuum breaker device conforming to ASSE 1001 or ASSE 1011, a pressure bleed device conforming to IAPMO PS-104 shall be used to protect the vacuum breaker device. The purpose is so that continuous pressure does not adversely affect the vacuum breaker device upstream of the pressure bleed device. This also protects against a cross - connection between hot and cold water migration by encouraging the user to turn off the water supply at the faucet.

Buckeye ECO EDGE™ - User Manual

Chemical Proportioning System



Single Dispense System




Buckeye International, Inc.


2700 Wagner Place • Maryland Heights • Missouri 63043 • USA • 314.291.1900

Quick Connect:

To properly connect ECO bag to ECO unit, refer to graphic panel (located in the center of section of unit) for instructions.




Note:
Make sure chemical lines are not pinched/kinked when installed.





 Do not cross Quick Connect Lines

Match icons with ECO Cleaner line label




Prime Chemical Lines:


After properly connecting ECO bag to ECO unit, engage switch (low flow switch) and button (high flow button) to allow chemical to fill lines completely (aprox. 20 seconds)
Make sure no air bubble remain in chemical lines before diluting chemical for use




Bucket Operation:



Unlock key is stored with spring clip under top of bucket



Unlock with Key:
Remove key from bucket, insert into top slot and pivot bucket forward.



Unlock without Key:
With Key stored in bucket, press down on slot and pivot bucket forward,

 Single Dispense System

